



PERTH SOLAR FORCE

Whether you are using your mobile phone/tablet or a laptop all the following instructions remain the same.

- 1) Ensure that your inverter is on. The green light should be on, the Orange light should be flashing twice, and the Red light should be off.
(Note: If the Orange light is on constantly with no flashes then your inverter is already connected to a Wi-Fi network. If the Orange light is flashing four times with a short pause, then there is an issue with the GoodWe server, and your inverter should automatically re-connect soon.)
- 2) On your selected device go to your Wi-Fi connections and connect to "Solar Wi-Fi", this is the inverter and the password is 12345678. Your phone may say that there is no internet connection, that is to be expected and will not affect the rest of the process.
- 3) Open your internet browser and in the address bar at the top enter 10.10.100.253 and press enter.
- 4) A box will pop up asking for a username and password, both are "admin".
- 5) If the screen opens with Chinese writing on it, in the top right-hand corner there is a small button to select English. Click on it and the page will re-load in English.
- 6) Near the bottom of the page there is a "Start Setup" button, click on it.
- 7) A list of available W-Fi networks should appear. If one doesn't appear or your network isn't on the list, click "Refresh". (If your network still doesn't appear please contact our office.) Click on the round dot on the left-hand side of the screen next to your Wi-Fi network name. Click "Next" at the bottom of the screen.
- 8) Enter the password for your Wi-Fi network. The password will be case sensitive. (if you select "Show psk" then you will be able to see what you have entered) Click "Next"
- 9) You will see a screen that says, "Save success". At the bottom of the screen click "Complete"
- 10) Disconnect your device from the "Solar Wi-Fi"
- 11) After a minute or two the Orange light on the front of your inverter should go solid orange with no flashes. If you are still getting two flashes, please return to set 3 and try again. (after two unsuccessful attempts please contact our office for further assistance). If you get 4 flashes on the orange light then your inverter has successfully connected to your Wi-Fi network but is having communication issues with the GoodWe server, this should correct its-self within 24 hours. If after 24 hours you still getting 4 flashes on the orange light, please contact our office.

If you experience any problems with these instructions or this doesn't rectify your issue, please contact our office on 1300 773 669 or (08) 9308 0335